

Error #	Description of Error
101	Valve not sensing valve movement with motor output energized
102	Valve unable to find next cycle position (stalled)
103	Valve unable to find next cycle position
104	Valve unable to find Home position
106	Aux MAV Motor RAN TOO LONG - unable to find proper park position
107	Aux MAV Motor RAN TOO SHORT, STALLED - unable to find proper park position
109	Internal Software Error - Error generated when proper software operation can no longer be maintained by the microcontroller due to the detection of an invalid motor state
116	Aux MAV Motor RAN TOO LONG - unable to find proper park position
117	Aux MAV Motor RAN TOO SHORT, STALLED - unable to find proper park position
201	Internal Software Error - Error generated when proper software operation can no longer be maintained by the microcontroller due to the detection of an invalid regeneration cycle
402	Nonvolatile Memory Failure - Error generated when the microcontroller can't operate properly due to a check sum error for the Operational Data and Status Section of EEPROM memory
403	Nonvolatile Memory Failure - Error generated when the microcontroller can't operate properly due to a check sum error for the Menu Section of EEPROM memory
404	Nonvolatile Memory Failure - Error generated when the microcontroller can't operate properly due to a check sum error for the Diagnostic Section of EEPROM memory
406	Nonvolatile Memory Failure - Error generated when the microcontroller can't operate properly due to a check sum error for the Contact Screen Section of EEPROM memory
407	Status RAM Memory Failure - Error generated when the microcontroller can't operate properly due to corrupted data contained in the Operational Data and Status Section of RAM memory. When this error is generated, the Error Mode is not entered nor an err
408	Diagnostic RAM Memory Failure - Error generated when the microcontroller can't operate properly due to corrupted data contained in the Diagnostic Section of RAM memory. When this error is generated, the Error Mode is not entered nor an error display view
410	Configurator Download Error - Configurator file downloaded to the control not originally uploaded from another control with the identical software revision

Ошибка	Описание ошибки
101	Клапан не запускается при подаче питания на двигатель
102	Заклинивание – клапан не находит правильную позицию поршня
103	Клапан не может найти правильную позицию поршня
104	Клапан не может найти исходную позицию
106	Превышение времени работы альтернатора
107	Заклинивание двигателя в режиме альтернатора
109	Системная ошибка – требуемая операция не может проводиться, так как был обнаружен сбой в работе двигателя
116	Превышение времени работы внешнего MAV клапана
117	Заклинивание двигателя внешнего MAV клапана
201	Системная ошибка – требуемая операция не может проводиться, так как был обнаружен сбой цикла регенерации
402	Сбой памяти – ошибка при считывании рабочих данных и данных раздела состояния устройства
403	Сбой памяти – ошибка при считывании данных раздела меню
404	Сбой памяти – ошибка при считывании данных раздела диагностики
406	Сбой памяти – ошибка при считывании данных раздела информации
407	Ошибка оперативной памяти – повреждение рабочих данных или данных состояния устройства
408	Ошибка диагностической памяти – повреждение диагностических данных. (Ошибка не отображается на дисплее)
410	Ошибка файла конфигулятора – данные конфигулятора загружены с устройства с некорректным программным обеспечением